

# E. B. Emory, Dr 1884

- 26. Making new Bridle Bit - <sup>Wilton</sup> 25-
- " Making & nailing 2 Plates on Colt <sup>grove</sup> 75-
- 28. 2 new Hooks & Rivet - Staple in <sup>Wilton</sup> Singletree 45-
- " Forging 2 & nail 4 Plates on colt - <sup>grove</sup> 87-
- " Tempering Tents for <sup>Wilton</sup> ~~colts~~ 25-
- " 31. new clines for new ground Plough <sup>Lynch</sup> 95-
- April 1. Sharpen Plough Coller 2 new <sup>Singletree</sup> ~~Hooks~~ <sup>Spurds</sup> 55-
- " 2. Strutting Plough Coller Plate on <sup>Lynch</sup> Singletree 30
- " 4. Splice ~~Rod~~ & cut Thread & new Bolt for Plough <sup>Lynch</sup> 40
- " Repair coller Splice Shear & Beane Rod <sup>Lynch</sup> 50
- 7. Fitting Irons on Plough 3 new long Bolts <sup>Lynch</sup> 75-
- " New Ranch & Key & clip & large link for <sup>Lynch</sup> clines 65-
- " Cut Thread on Bolt & new nut for <sup>Lynch</sup> Plough 10
- " 3 new Shoes on 1 on colt - 2 on mare <sup>grove</sup> 75-
- " 8. nail 2 Shoes <sup>grove</sup> - <sup>Spurds</sup> 30
- " 14. Sharpen 20 Harrow Teeth & Put in <sup>grove</sup> Harrow 50
- Nov. 9. new Bolts. & 1 new Tooth in <sup>Spurds</sup> Harrow 62
- " " Sharpen & Tempering Plow Shear <sup>Spurds</sup> 50
- " 15. Barrening 5 Teeth in Harrow 1 new <sup>grove</sup> Bolt in do. 20
- " 16. Repair clines For Plough <sup>grove</sup> ~~Wilton~~ 10
- " " 4 long Bolts for <sup>Spurds</sup> Press 75-
- " 16. 4 new Staples & Rings <sup>grove</sup> 80
- " 18. New Chane for Drag Harrow / link in <sup>Lynch</sup> chane 150-
- " 19. Forging 2 Horse Tree Rivet Staples <sup>Wilton</sup> 75-
- 21. 50 Rivet Head nails for <sup>Spurds</sup> Spurds 75-
- " 23. Large Bolt For Wagon Cupling <sup>Spurds</sup> 25-
- " 25. 1 new Bolt For corn Sheller <sup>grove</sup> 10

1444  
1454