brg12_1_211-0173 © Baltimore City Archives

DIRECTIONS.

Item a small cord or wire across the top of the shade, and draw it through the groove.
Fasten on the brackets, round head tacks, tacked on the right.
Put up the roller in the brackets, with shade rolled up.
Be sure the roller works freely in the brackets.
If the extension or plug is pulled out, see that it is so it will not slip back into the tube.
If the spring is not strong enough, draw the shade down about two feet, take from brackets, wind up, then replace.
If too strong, wind up, then replace.

M 463 — 1771